Assembly Instructions


Tools Required: Powered Screwdriver



Assembly Instructions

 To prevent possible scratches or damage, assemble the bookcase on a soft surface such as a blanket, carpet or packaging.





Assembly Instructions

Parts

| Item | Description | Qty | Item | Description | Qty |
|------|------------------|-----|-----------|--------------------|-----|
| А | Top Panel | 1 | C2 | 5/8" Cam Cover | 18 |
| X | Left Side Panel | 1 | Pl | Threaded Dowel Pin | 10 |
| Z | Right Side Panel | 1 | SI | 4x25 Screw | 12 |
| D | Back Panel | 1 | M2 | Metal Feet | 4 |
| G | Bottom Panel | 1 | | | |
| Е | Moveable Shelf | 2 | | | |






P1 10 x Thread Dowel Pin





















Assembly Instructions

Step 1

Preparation for panels X, Z and D.

Connect cam bolts and dowels on panel $\bf D$ to the holes on panel $\bf X$, $\bf Z$ and tighten in a clockwise direction as illustrated below.




Assembly Instructions

Step 2

Preparation for panels X, Z, D, A and G.

Connect cam bolts and dowels on panel **X**, **Z** and **D** to the holes on panel **A** and **G** and tighten in a clockwise direction. Fix metal feet **M2** to the bookcase bottom panel with screws **S1** as illustrated below.




Assembly Instructions

Step 3

Moveable shelf assembly.

Insert adjustable shelf support pins **P1** into panels **X** and **Z**. Place panels **E** on the top of the shelf support pins **P1** as illustrated below.





Completed

